


wired for innovation



Lithium Deep Cycle Battery Installation & User Instructions

LB30C / LB70C / LB100C

Contents

Safety	2
General Advice	2
Disposal Information	2
Overview	2
Key Features.....	2
Installation	3
Safety Warnings.....	3
Wiring & Fusing.....	3
Connections	3
Parallel & Serial Options.....	4
Charging Options	4
Battery State of Charge calibration.....	5
Operation	5
Charging	5
Discharging.....	6
Undervoltage Protection.....	6
Overcurrent Protection	6
Storage	7
CAN Bus Interface	7
Specification	8

Safety

General Advice

- Only charge with a lithium approved charger
- Not suitable for engine cranking
- Do Not - Short circuit battery terminals
- Do Not - Crush, puncture or incinerate
- Do Not - Expose to temperatures above 132°F (50°C)
- Do Not - Open housing or attempt to disassemble
- Do Not - Install battery in an inverted position

Disposal Information



Li-ion



Disposal of lithium batteries marked with the recycling symbol should only be done at a certified recycling location. Batteries must not be mixed with domestic or industrial waste.

Overview

The Sargent range of lithium deep cycle batteries provide a simple drop-in replacement for most lead acid batteries used in leisure applications. They provide significant advantages over lead acid, including reduced weight, longer life, a more useable capacity and faster charging. Using optional CAN Bus communication, the batteries are able to integrate with Sargent power control systems to provide additional battery management features.

Key Features

- Light Weight - typically less than 50% weight of lead acid batteries
- Long Life - typically x10 cycle life of lead acid batteries
- More Useable Capacity - Up to 100% useable energy
- Fast Charging - Up to x4 faster charging than lead acid batteries

Installation

The battery can be installed vertically or horizontally but should never be installed in an inverted position. The battery should be held firmly in place by suitable straps or mounting brackets.

Safety Warnings

- Do not install in a sealed environment or adjacent to heat sources
- Do not install in an environment that may be subject to high humidity or water splashes
- Do not use with damaged or inadequately rated cables
- The battery must be protected by a suitably rated fuse

Wiring & Fusing

In order to reduce voltage losses, it is recommended to keep cabling runs as short as possible from the battery to the power distribution unit. Please refer to the table for recommended wiring gauges depending on length and required fuse rating

Fuse	Battery to Distribution Unit distance	
	Up to 3m	Up to 6m
20A	3mm ² / 14AWG	4mm ² / 12AWG
30A	4mm ² / 12AWG	6mm ² / 10AWG
40A	6mm ² / 10AWG	10mm ² / 8AWG

Connections


The connecting cables should be terminated with ring terminals suitable for connection to bolts supplied (M5 for LB30C, M8 for LB70C/100C). Use the supplied bolt, spring washer and plain washer, as shown below.



First connect load positive (+) cable to battery positive (+) terminal. Next connect the load negative (-) cable to battery negative (-) terminal. Check both terminals are fully tightened, 20Nm is recommended. Ensure the terminals are suitably protected against short circuit, for example if the battery is mounted under a seat.


Parallel & Serial options

It is possible to connect up to four batteries in parallel or series. Before connecting together, it is important to fully charge all batteries to ensure the terminal voltages are the same.



Charging options

Below are recommended connections for a battery charger. Always ensure the charger is suitably fused to protect cabling.



When fitted in a leisure vehicle, the battery can be re-charged from a number of sources such as, a mains charger, the vehicle battery/ alternator (during driving) or solar panel (via a regulator). To ensure

optimal charging, it is recommended to use a lithium compatible charger or one which can be configured to be suitable for lithium. Below are the recommended charging parameters

Parameter	LB30C	LB70C	LB100C
Bulk Current	15A (max)	35A (max)	50A (max)
Boost(Absorption) Voltage	14.2 - 14.6V	14.2 - 14.6V	14.2 - 14.6V
Float Voltage	13.8 - 14.0V	13.8 - 14.0V	13.8 - 14.0V

Due to the high charging currents possible when charging lithium batteries, it is recommended to fit a DC-DC charger when charging from the vehicle battery/alternator during driving, rather than a traditional split charge relay. This will help limit the current during charging and prevent overloading of cabling and/or fuses.

Battery State of Charge calibration

After installation of a new battery, it will take a few charge / discharge cycles before the Battery Management System (BMS) is fully calibrated to the battery charger being used. During this time, if a compatible Sargent display is being used to show battery information, it may not initially indicate 100% state of charge when the battery is full. This is normal and part of the self-calibration of the battery.

Operation

Charging

Always switch off the charger before connecting or disconnecting the battery.

To maximise cycle life, it is recommended to use a charger which is able to switch off or fall back to a float voltage once the charge cycle is complete.

The battery has protection against cold weather charging and will not accept charge if the temperature is below 0°C

The battery can be recharged at any state of charge without effecting

performance and should be fully charged before using for the first time. For optimum lifespan it is not recommended to charge at a rate greater than 0.5C e.g. 35A for a 70Ah battery

Discharging

It is not recommended to discharge the battery continuously at currents greater than 1C e.g. no more than 70A for a 70Ah battery

When discharging at temperatures below 0°C, there will be some capacity loss e.g. at -20°C the capacity will drop to around 70%

To avoid activation of the batteries Undervoltage Protection (UVP) it is recommended to set protection on the connected equipment to a higher voltage than the battery undervoltage protection.

Undervoltage Protection

If the battery becomes deeply discharged, the output will be automatically switched off by the Battery Management System (BMS) in order to help protect the battery. To recover a battery from this sleep state, connect a battery charger and allow it to fully re-charge.

To help avoid deep discharge:-

- Fully charge the battery before winter storage of the vehicle
- During storage, check no equipment is left connected to the battery which could totally discharge the battery

Overcurrent Protection

The battery is suitable for supplying heavy loads up to 1C, for example the 70Ah battery is able to supply up to 70amps continuous current. If this current is exceeded by using heavy loads, then the battery management system (BMS) will shut down the battery to protect itself. Please check the load is suitable for the rating of battery being used, for example when using a motor mover or power inverter.


Storage

- Never store that battery in a discharged state as this will reduce life
- Before storage it is recommended to fully charge the battery.
- During long term storage, the battery should be re-charged at least once every six months.
- For extended storage periods, it is recommended to keep the battery indoors but if this is not possible the following guidelines should be used

Storage time	Storage temperature
Up to 1 month	-20 to +60°C
1 – 3 Months	-10 to +35°C
Over 3 months	+15 to +35°C

CAN Bus Interface

The CAN Bus interface is for manufacturer use only and allows the unit to be monitored and controlled from compatible Sargent display panels.



A magnetic CAN Bus cable is available to allow connection of the battery to the Sargent CANBus network (Part: 17302)

Pin	Function
1	CAN H
2	No connection
3	CAN L
4	No connection



Specification

Model	LB30C	LB70C	LB100C
Nominal capacity	30Ah	70Ah	100Ah
Nominal voltage	12.8V	12.8V	12.8V
Rec. Boost charge voltage	14.2 - 14.6V	14.2 - 14.6V	14.2 - 14.6V
Rec. Float charge voltage	13.6 - 13.9V	13.6 - 13.9V	13.6 - 13.9V
Max rec. charge current	15A	35A	50A
Max cont. discharge current	30A	70A	100A
Max pulse current (3 secs max)	60A	140A	200A
Undervoltage protection / recovery	10V / 11.2V	10V / 11.2V	10V / 11.2V
Self discharge (per month)	< 3%	< 3%	< 3%
Form factor	-	Group 24	Group 31
Terminals	M5	M8	M8
Dimensions (L x W x H)	180x76x168	260x168x218	329x172x223
Nett Weight	3.18kg	8.70kg	11.21kg

Notes

Notes



Sargent Electrical Services Ltd

Unit 39, Tokenspire Business Park, Beverley, East Yorks, HU17 0TB, UK

Phone: +44(0)1482 881655 | Fax: +44(0)1482 678987

Email: support@sargentltd.co.uk

Tech Support: +44(0)1482 678981



H013